



## Parts List for DC930KA Type 1

Item Number	Part Number	Description	Qty Required
1	629820-01	CLAMSHELL SET	1
2	629823-00	END CAP	1
3	148354-03	BIT CLIP	2
4	395657-00	ID LABEL	1
5	633327-02	FWD/REV BUTTON	1
6	152274-25	VSR SWITCH	1
7	629172-00	ADAPTER PLATE	1
8	156179-01	SCREW,TAPTITE	2
9	629151-01	MOTOR & PINION	1
10	682211-00	SCREW,TORX	5
11	613237-00	TRANSMISSION	1
12	330075-72	KEYLESS CHUCK	1
12	330075-63	KEYLESS CHUCK	1
13	330019-62	SCREW,THD.FORM	8
14	631282-01	LEADWIRE ASSY.	1
15	631283-01	LEADWIRE ASSY.	1
16	636634-00	MOTOR LEAD WIRE GUIDE	1
17	N009876	NAMEPLATE	1
18	603754-01	BRUSH BOX	2
19	605256-01	SCREW	1
20	640421-00	INSTRUCTION LABEL	1
21	330019-00	SCREW	3
24	609133-00	CAP	1
25	629462-00	ADJ.COLLAR	1
26	395460-00	DETENT SPRING	1
27	647170-00	SPINDLE HOUSING ASSY	1
28	397875-00	SPINDLE ASSY.	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for DC930KA Type 1

Item Number	Part Number	Description	Qty Required
35	638581-00	GEAR & SPINDLE	1
36	646594-00	SIDE HANDLE	1
37	629827-00	COLLAR PIN	1
38	613217-00	CLUTCH SPRING	1
39	635718-00	CLUTCH PIN	1
836	233804-41	MANDREL	1
836	233804-40	CHUCK REMOVAL FIXTURE	1
836	559697-99	INSERT	1
856	607918-41	SCREWDRIVER BIT	1
861	660141-00	KITBOX	1
866	DC9091	BATTERY PACK	2
867	645221-00	BATTERY CAP	2
871	388683-12	1 HOUR CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.