



Parts List for DC841KA Type 2

Item Number	Part Number	Description	Qty Required
1	658395-01	CLAMSHELL	1
2	646693-00	NOSE CONE	1
3	608116-00	ANVIL ASSY.	1
4	642883-00	WASHER - URETHANE	1
5	608115-00	O RING	1
6	608114-00	HOG RING	1
10	642880-00	MECHANISM ASSY	1
11	646694-01	ARMATURE ASSEMBLY	1
12	640537-00	MAGNET RING	1
13	640550-00	BRUSH HLDR/BRUSH ASY	1
14	N031377	BRUSH HLDR/BRUSH ASY	1
15	N019949	VSR SWITCH (DC)	1
16	659201-00	FWD/REV BUTTON	1
17	642886-00	CONE	1
18	682211-00	SCREW,TORX	9
19	148354-03	BIT CLIP	1
20	N009137	NAMEPLATE	1
21	646763-00	IDENT. LABEL	1
22	650677-00	WARNING LABEL (SPA)	1
24	659916-00	BELT CLIP	1
25	330013-03	SCREW	1
861	392088-00	KITBOX	1
861	392088-00	KITBOX	1
861	392088-00	KITBOX	1
866	DC9071	BATTERY PACK	2
867	645221-00	BATTERY CAP	2
871	388683-12	1 HOUR CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.