



## Parts List for DG4400B Type 1

Item Number	Part Number	Description	Qty Required
1	642816-01	LOWER FRAME	1
2	641402-01	ROLLBAR ASSEMBLY	1
3	640010-01	UPPER FRAME ASSY	1
4	640940-00	ENGINE	1
4	640940-00	ENGINE	1
5	641906-00	ALTERNATOR	1
6	5140063-28	FUEL TANK	1
7	GS-0087	ASSY BEARING BALL RO	1
9	641800-00	BUSHING	4
10	637707-00	ISOLATOR	4
11	640062-00	GROMMET	2
12	637768-00	GROMMET	1
13	640059-00	INSERT	3
14	640058-00	GROMMET	3
18	637766-00	RUBBER SEAL	1
20	640060-00	INSERT	2
21	645055-01	BOLT	2
22	645055-00	BOLT	4
23	A17233	SELF TAPPING SCREW	4
25	645025-00	BOLT	5
26	645033-00	WASHER	5
27	645029-00	SELF TAPPING SCREW	2
28	645024-00	NUT	8
30	644407-00	NAMEPLATE	1
38	1000002066	HOSE CLAMP	1
39	D21172	SCREW .250-20X.500 H	1
40	646564-00	WARNING LABEL	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for DG4400B Type 1

Item Number	Part Number	Description	Qty Required
42	N004046	WARNING LABEL	1
103	285816-20	FUEL CAP	1
104	285816-34	FUEL FILTER	1
105	285816-35	GAUGE	1
106	285816-21	BOLT	2
107	285818-33	FUEL VALVE	1
107	285816-18	FUEL VALVE	1
108	285816-54	LABEL	1
109	285816-58	ID LABEL	1
110	285816-57	ID LABEL	1
206	647133-00	AXLE	1
208	647128-00	WASHER	2
209	647122-00	WHEEL	2
210	647129-00	WASHER	2
211	647151-00	COTTER PIN	2
212	648587-00	FOOT	2
220	647154-00	L. HANDLE CLAMP	1
221	647125-00	HANDLE GRIP	2
222	647734-00	LEFT HANDLE	1
227	647735-00	RIGHT HANDLE	1
228	647127-00	R. HANDLE CLAMP	1
229	641758-00	ASSY SKYHOOK PAINTED	1
230	647124-00	BRACKET	2
254	647160-00	BOLT	18
260	GS-0748	CAPACITOR 40UF 370V	1
261	GS-0595	BRACKET CAPACITOR 2.	1
262	GS-0862	O-RING ROTOR BEARING	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for DG4400B Type 1

Item Number	Part Number	Description	Qty Required
263	SSF-553-1	SCREW #10-24X.563 TH	5
264	SS-6506-CD	WASHER FLAT	2
265	GS-0872	RESISTOR 10K OHM	2
266	GS-0871	DIODE 10AMP 1000V	2
267	GS-0118	STRAP GROUND	1
268	SSF-577	SCREW .375-16X1.00 H	4
269	SSN-619	WASHER .375 SPRING L	4
270	GS-0767	RECTIFIER	1
271	D28006	BOLT ROTOR THRU 2.75	1
272	D26295	BOLT	4
273	A19023	END COVER	1
280	GS-0644	RECEPTACLE GFCI 120V	2
281	GS-0445	RECEPTACLE 4 PRONG T	1
282	GS-0480	RECEPTACLE 125V 20A	1
284	Z-D21508	BREAKER CIRCUIT125/2	3
285	D27260	SWITCH IDLE CONTROL	1
286	D29076	ASSY BOARD CIRCUIT I	1
286	D29076	ASSY BOARD CIRCUIT I	1
287	330019-13	SCREW,M4X19	4
288	N001190	START SWITCH	1
289	637671-00	BEZEL	1
290	N003926	HOUSING COVER	1
291	N003924	HOUSING,ASSY.	1
292	1000003117	TERMINAL BOARD	1
293	641521-02	CIRCUIT BREAKER	1
294	1000002764	SWITCH	1
295	1000003737	BATTERY COVER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenetwork.com](http://www.dewaltservicenetwork.com) for current parts information.

## Parts List for DG4400B Type 1

Item Number	Part Number	Description	Qty Required
296	330019-48	SCREW	4
297	N028923	TETHER	1
300	643150-00	PANEL ASSEMBLY	1
321	643315-00	BOLT	1
322	643316-00	NUT	1
323	643317-00	WINGNUT	1
350	A10861	STATOR	1
351	A10860	ROTOR	1
352	637709-00	END BELL	1
353	D26601	DRIVE END ADAPTER	1
400	285814-01	BOLT	4
401	285815-94	DRAIN PLUG	2
402	285814-03	BOLT	1
404	285814-06	BOLT	2
406	285814-08	WASHER	1
407	285814-10	WASHER	2
408	285814-12	SPECIAL NUT	1
409	285814-13	OIL SEAL	2
410	285814-16	DOWEL PIN	2
411	285814-18	DOWEL PIN	2
412	285816-28	BALL BEARING	2
413	285814-23	SPARK PLUG	1
413	285814-23	SPARK PLUG	1
414	285814-25	GASKET	1
415	285814-28	GASKET	1
416	285814-30	CYLINDER HEAD	1
417	285814-33	COVER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for DG4400B Type 1

Item Number	Part Number	Description	Qty Required
418	285814-34	BOLT	1
419	285814-36	CRANKCASE	1
420	285816-15	SWITCH	1
421	285814-40	OIL ALERT UNIT	1
422	285814-42	CASE COVER	1
423	285814-45	GASKET	1
424	285814-48	CAP ASSY.	1
427	285814-53	CRANKSHAFT	1
428	285817-20	WOODRUFF KEY	1
429	285814-58	PIN	1
430	285814-60	CLIP	2
431	285814-63	RING SET	1
432	285814-66	CONNECTING ROD	1
433	285814-69	LIFTER	2
434	285814-71	PUSH ROD	2
435	285814-74	VALVE	1
436	285814-77	VALVE	1
437	285814-80	VALVE SPRING	2
438	285814-83	RETAINER	4
439	285814-85	SEAL	1
440	285814-87	ROTATOR VALVE	1
441	285814-90	CAMSHAFT	1
442	285814-93	PLATE ASSY.	1
443	285814-95	ARM ASSY	2
444	285815-00	SHROUD	1
445	285815-03	GASKET	1
446	285815-07	GASKET	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for DG4400B Type 1

Item Number	Part Number	Description	Qty Required
447	285815-09	CLIP	4
448	285815-10	CLIP	1
449	285816-48	CONTROLLER	1
450	285815-15	FAN	1
451	285815-18	STARTER PULLEY	1
452	285815-21	FLYWHEEL	1
453	285815-23	GROMMET	1
454	285816-39	GROMMET	1
455	285815-26	IGNITION COIL	1
456	285815-28	COIL	1
457	285815-30	GASKET	1
458	285815-34	GASKET	1
459	285816-47	MANIFOLD	1
460	285814-55	PISTON	1
461	285815-39	SPRING	1
462	285815-41	SPRING	1
463	N038216	ARM	1
464	285815-47	SHAFT	1
465	285815-49	LOCK PIN	1
466	285815-52	GOVERNOR ASSY.	1
467	285816-65	STARTER	1
468	285815-55	CONTACTOR	1
470	N035918	STARTER ASSY.	1
471	285815-62	INSULATOR	1
471	285815-62	INSULATOR	1
472	285815-12	CARBURETOR	1
473	285815-66	AIR FILTER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for DG4400B Type 1

Item Number	Part Number	Description	Qty Required
474	285815-70	CONTROL ASSY	1
475	285818-08	HOSE	1
476	285815-73	NUT	5
477	285815-74	NUT	9
478	285818-96	CLAMP	2
481	285815-83	BOLT	2
482	285815-86	BOLT	5
483	285815-88	BOLT	7
484	285815-90	BOLT	3
487	285816-37	BOLT	2
488	285815-96	HOUSING COVER	1
489	285814-04	BOLT	2
491	285816-04	BLOWER HOUSING	1
492	285816-07	BUSHING	1
493	285816-08	BRACKET	1
494	285815-69	MUFFLER	1
495	285816-13	ROD	1
496	285816-24	STUD	3
497	285816-25	CABLE TIE	1
500	285816-32	SOLENOID	1
500	285816-32	SOLENOID	1
501	SSF-928	SCREW .313-18X.875 H	2
502	D26800	SCREW .313-18X2.00 H	2
503	285816-36	BOLT	2
504	SSF-8150	NUT .312-18 UNC HEX	2
505	285814-88	SEAT	2
506	285816-45	RETAINER	2

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for DG4400B Type 1

Item Number	Part Number	Description	Qty Required
507	285816-46	GASKET	1
508	285816-40	CONNECTING WIRE	1
509	285815-93	BOLT	9
510	285816-49	LABEL	1
511	285816-50	LABEL	1
511	285816-50	LABEL	1
512	285816-53	ID LABEL	1
515	1000002766	LABEL	1
516	285816-61	BRACKET	1
517	285816-62	MUFFLER COVER	1
518	285816-63	MUFFLER COVER	1
519	285816-64	NUT	2
520	285816-55	BOLT	2
522	285816-68	SPARK ARRESTOR	1
523	285816-67	BOLT	2
524	285816-76	RATCHET	2
525	285816-96	SPRING	1
526	285816-78	BOLT	1
527	285816-79	SPRING	2
528	285816-80	PULLEY	1
529	285816-81	SPRING	1
530	285816-82	ROPE	1
531	285816-83	CAP ASSY.	1
532	285818-24	AIR FILTER	1
533	285818-24	AIR FILTER	1
534	285816-75	COVER	1
535	285816-87	FLOAT	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicen.com](http://www.dewaltservicen.com) for current parts information.

## Parts List for DG4400B Type 1

Item Number	Part Number	Description	Qty Required
536	285816-88	VALVE	1
537	285816-89	BOWL	1
538	285816-90	PIN	1
539	285816-91	O-RING	1
540	285816-92	NOZZLE	1
541	285816-93	SCREW	1
542	285816-94	GASKET	1
543	285817-17	MAIN JET	1
543	285816-95	MAIN JET	1
544	285816-84	SOLENOID	1
545	285816-86	SPRING WASHER	2
546	285816-85	SCREW	2
547	285816-97	SCREW	1
548	285817-04	SEAL	1
549	285817-03	NUT	6
550	5140010-05	LOCK WASHER	9
551	285815-85	BOLT	9
552	1349856	PAN HEAD SCREW	1
553	285817-19	SPRING	1
554	285815-31	TUBE	1
555	285817-46	FUEL FILTER	1
555	5140062-32	FUEL FILTER	1
556	285818-26	GASKET	1
557	285818-27	BOLT	1
558	285818-28	O-RING	1
559	285818-39	HANDLE	1
806	D23215	OIL SAE 10W-30 SJ 32	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.

## Parts List for DG4400B Type 1

Item Number	Part Number	Description	Qty Required
856	647134-00	WHEEL KIT	1
866	DC9096	BATTERY PACK	1
871	388683-12	1 HOUR CHARGER	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit [www.dewaltservicenet.com](http://www.dewaltservicenet.com) for current parts information.