



Parts List for DCD780C2 Type 1

| Item Number | Part Number | Description | Qty Required |
|-------------|-------------|----------------------|--------------|
| 1 | N031365 | TRANSMISSION ASSY. | 1 |
| 2 | N061233 | CLAMSHELL SET | 1 |
| 3 | N089939 | SWITCH VSR | 1 |
| 4 | 682211-00 | SCREW,TORX | 12 |
| 5 | 654258-00 | BRUSH RING ASM | 1 |
| 6 | N039788 | FORWARD/REV SELECTOR | 1 |
| 7 | N092054 | CHUCK,KEYLESS | 1 |
| 8 | N035580 | MAGNET RING | 1 |
| 9 | N042178 | ARMATURE ASSEMBLY | 1 |
| 10 | N092854 | CHUCK SCREW | 1 |
| 11 | N078822 | IDENT. LABEL | 1 |
| 13 | N071836 | ROLL PIN | 1 |
| 14 | N042665 | MACHINE SCREW | 2 |
| 15 | N086039 | BELT HOOK | 1 |
| 16 | N098881 | BIT HOLDER ASSY | 1 |
| 24 | N078823 | WARNING LABEL (SPA) | 1 |
| 25 | N078824 | NAMEPLATE | 1 |
| 800 | N017298 | GREASE | 1 |
| 861 | N068611 | KITBOX | 1 |
| 866 | DCB201 | BATTERY PACK | 2 |
| 871 | DCB101 | CHARGER | 1 |

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.